

- The sound is fuller in the maximum position and thinner in the minimum position.
4. Harmonic Coloration Switch - This two position switch selects between two distinct sounds. One is a full rich sound, the other a hollow synthetic sound.
 5. Treadle - The treadle or foot pedal controls the rate of flanging or chorus. The flanging or chorus is slowest with the toe up, approximately 1 cycle every 15 seconds. The fastest rate with the toe down is approximately 15 times per second. The rate can be varied while playing or will remain at any desired rate when your foot is removed.

IN CONCLUSION

The Morley Chorus Flanger can be used with many other effects such as (but not limited to) the Morley Electrostatic Delay Line or Power Wah Fuzz. Do not hesitate to experiment. Its full potential is dependent upon your own creativity and talent.

WARRANTY


Morley pedals are state of the art products built to the highest professional standards of quality therefore, for one year from the date of purchase, Morley warrants its products to be free from defect, to the original consumer purchaser, provided that:

1. The product has not been damaged, or abused.
2. The product has not been altered, or repaired by the customer or an unauthorized service center.
3. The serial number has not been altered or erased.
4. The guarantee card is filled out, and returned to us within 10 days from date of purchase.
5. The purchaser returns the product to us freight prepaid in the event that service is required.

Once the above conditions are met, Morley will repair or replace the product, without charge to the purchaser for the one year guarantee period.

Thank you for buying Morley

STEREO CHORUS FLANGER INSTRUCTION MANUAL



MORLEY®

A Division of Tel-Ray Electronics Mfg. Co., Inc.
P.O. Box 1000, New York, N.Y. 10001

(CFL)