

chorus-vibrato depth. Use of both the depth and mix controls allows adjustment of chorus-vibrato effects from perceived subtle amplitude modulation to wildly swinging frequency modulation.

STEREO OPERATION

Stereo or other effects are automatically generated by plugging a second amplifier into the "Stereo Amplifier" jack. The two speakers should be as far apart as practical and always over 10 feet if both speakers are facing in the same direction. Amplifier volume controls should be adjusted so that listeners receive equal sound from both sources.

In "Echo" or "Chorus-Vibrato" modes, direct and delayed signals are split and applied to separate amplifiers. This allows the mixing to take place in the ears and mind of the listener. The "Mix" control has no effect when in stereo mode.

IMPORTANT NOTES

1. In order to hear echo effects clearly, always use short percussive or sudden damping as opposed to sustained or ringing notes. A long tone tends to mask the effect. This is also true of natural echoes.
2. Do not be afraid to experiment with the unit. You cannot damage the unit or the amplifier by experimenting with the controls.
3. Caution must be observed when plugging the unit into a power source. A 120 volt unit plugged into a 240 volt source will cause instant and serious damage when turned on. A 240 volt unit plugged into a 120 volt source will not be damaged but it will not operate.


Morley pedals are built to the highest professional standards. For one year from the date of purchase Morley warrants its products to be free from defect to the original consumer provided:

1. The product has not been damaged or abused.
2. The product has not been altered or repaired by the customer or an unauthorized service center.
3. The serial number has not been altered or erased.
4. The guarantee card is filled out and returned to us within 10 days from date of purchase.
5. The purchaser returns the product to us freight pre-paid in the event service is required.

Once the above conditions are met Morley will repair or replace the product, at its option, without charge to the purchaser for the one year guarantee period.

ECHO-CHORUS-VIBRATO

INSTRUCTION MANUAL



ECV

MORLEY