

Thanks for buying the Morley® Cliff Burton Fuzz Box

The Cliff Burton Fuzz Box takes the fuzz circuit from the Cliff Burton Power Fuzz Wah in a stand alone stomp box. The Modern / Vintage Fuzz types are now foot-selectable and we added a tone knob for greater tone range.

CONNECTIONS: The Cliff Burton Fuzz Box powers from one 9V battery or optional Morley Adapter (DC jack is located next to INPUT jack). Using a standard guitar cable, simply plug guitar into INPUT jack, connect a standard guitar cable from the OUTPUT jack to the Input of your amplifier.

FUNCTIONS AND FEATURES:

The right side switch turns on/off the fuzz. The LED will light when fuzz is turned on. There are three knobs that control fuzz sound:

INTENSITY: Controls fuzz from mild clip to full on fuzz madness.

TONE: Controls tone of fuzz.

LEVEL: Controls the overall loudness of the fuzz.

The left side switch chooses between Modern or Vintage Fuzz types. When LED is lit you are in Vintage mode, when LED is off, you are in Modern mode.

This product is warranted for two years from date of purchase with a copy of your purchase receipt. To obtain warranty service, please contact Morley® customer service at tech@morleyebtech.com