

## GENERAL INFORMATION

The Morley Analog Echo Reverb is one of the finest devices in its class. A few moments of reading this pamphlet will provide a much shorter "getting familiar" period. The AER may be used with any amplified instrument or microphone with normal range of impedance. Always use good quality shielded cable to minimize interference, noise, or hum. The AER may be used with two 9 volt alkaline batteries or an external AC (mains) adapter.

## OPERATING INSTRUCTIONS

- 1 - Connect the signal source, instrument, or microphone to the input jack. This actuates a switch and turns the power on. One of the indicating lamps (LED) (depending on the push switch position) will come on.
- 2 - Connect the amp to the output jack.
- 3 - Turn the controls on the amp and instrument to their usual settings.
- 4 - Turn delay knob and mix to 12 o'clock. Turn repeats to counter clockwise position (7 o'clock).
- 5 - Turn on the amplifier and instrument and the AER to effects "on" position.
- 6 - Generate a damped sound by tapping a mike or a muted string. You will hear the direct (dry) sound plus the delayed sound produced by the AER.
- 7 - Rotating the delay knob will increase or decrease the echo time (or speed) from 17 milliseconds to 300 on the AER and 600 ms on the AER-6.
- 8 - Rotate the repeat knob in a clockwise direction while producing damped sounds; with delay time at maximum setting. The further the knob moves clockwise, the more repeats are produced.
- 9 - The mix control varies the delayed and direct signal balance. Rarely should the echo be made louder than the direct. For reverb sounds the delay is made quite soft and the repeats quite rapid. Some experimenting will quickly make you an expert for your style of playing.

## WARRANTY

MORLEY PRODUCTS ARE STATE OF THE ART BUILT TO THE HIGHEST PROFESSIONAL STANDARDS OF QUALITY. THEREFORE, FOR ONE YEAR FROM THE DATE OF PURCHASE, MORLEY WARRANTS IT'S PRODUCTS TO BE FREE FROM DEFECT TO THE ORIGINAL CONSUMER PURCHASER, PROVIDED THAT:

1. THE PRODUCT HAS NOT BEEN DAMAGED OR ABUSED.
2. THE PRODUCT HAS NOT BEEN ALTERED OR REPAIRED BY THE CUSTOMER OR AN UNAUTHORIZED SERVICE CENTER.
3. THE SERIAL NUMBER HAS NOT BEEN ALTERED OR ERASED.
4. THE GUARANTEE CARD IS FILLED OUT AND RETURNED TO US WITHIN TEN DAYS FROM DATE OF PURCHASE.
5. THE PURCHASER RETURNS THE PRODUCT TO US FREIGHT PRE-PAID IN THE EVENT THAT SERVICE IS REQUIRED.

ONCE THE ABOVE CONDITIONS ARE MET MORLEY WILL REPAIR OR REPLACE THE PRODUCT WITHOUT CHARGE TO THE PURCHASER FOR THE ONE YEAR GUARANTEE PERIOD.

M O R L E Y

A Division of TEL RAY Electronics Mfg. Co., Inc.  
6855 VINELAND AVE.  
NO. HOLLYWOOD, CALIF. 91605  
U.S.A.